



ADVICE

MICROSOFT LICENCE


Each PC with a Windows software system must have a licencesticker.

We just added the sticker as opposed to apply the sticker, because it's a little bit dangerous to apply the sticker before your first assembly. The sticker might get damaged and your licencekey can become unreadable.*

- 1** Connect your device with a standard display via hdmi & activate.
- 2** Save & archive your licencekey.
- 3** Push your device without the sticker into the OPS slot of your Display. Check your device for scratches.
- 4** Apply your sticker on a scratch free place.

* Just in case your licencekey got damaged by your assembly, DELO assumes no liability.

Step Electronic GmbH
Lise-Meitner-Straße 1
45659 Recklinghausen
www.step-systeme.de



OPS QUICK START GUIDE

YOUR FIRST STEP

⚠ Please read this guide before installation!



LOOK OUT!


Before connecting your OPS system with your display, please read our tips:

- ⚠ Before you connect the OPS system ensure that your display isn't plugged in anymore.
- ⚠ Apply your system correctly otherwise your warranty will expire. Additionally the case or even the hardware inside your OPS will cause some damage.
- Check your system! Due to transport the bolts can get loosely.
- Notice: The first installation can take some time until the system starts. Don't cancel this process, wait!
- With an optional external power supply unit you can do this outside the display. To do this, you should use the OPS with an external monitor cable connector.


LET'S GET STARTED

APPLY YOUR OPS

Keep in mind that the fan of your OPS system has to be in front of the wall. Your display should be 3 centimeters away from the wall otherwise a airing cycle can't be guaranteed.



Sidewise apply, Fan in front of the wall, the antennas should be aimed to the open side of the Display!



Bottom apply, Fan in front of the wall, the antennas should be aimed to the open side of the Display!